



<u>tip ht (in)</u>	<u>dried line width (in)</u>
0.25	0.216
1	0.45
2.25	0.617
4.5	1.025

Conditions+Parameters

60kHz nozzle
 Tap H2O w black dye (mccormick 'food dye') on printer paper
 1.0mL/min 45% power, aapa on, cp off, standard mode
 40mm/sec line speed ~73F room temp.

width measured after paper left drying

SSA:
 compressed air, 1/4" OD 3/16"ID vinyl tubing
 For this set, similar line widths apparent at 1,3,5psi